



# LED TV

Chassis : U90A

Model : UE40F80\*\*\*\*

UE46F80\*\*\*\*

UE55F80\*\*\*\*

## ***SERVICE*** Manual

### LED TV



UE\*\*F80\*\*\*\*

### Contents

1. Precautions
2. Product specifications
3. Disassembly and Reassembly
4. Troubleshooting
5. Wiring Diagram

# Contents

<b>1. Precautions .....</b>	<b>1-1</b>
1-1. Safety Precautions .....	1-1
1-1-1. Warnings.....	1-1
1-1-2. Servicing the LED TV .....	1-1
1-1-3. Fire and Shock Hazard .....	1-1
1-1-4. Product Safety Notices .....	1-2
1-2. Servicing Precautions.....	1-3
1-2-1. General Servicing Precautions .....	1-3
1-3. Static Electricity Precautions .....	1-4
1-4. Installation Precautions .....	1-5
<b>2. Product Specifications.....</b>	<b>2-1</b>
2-1. Detailed Specifications .....	2-1
2-2. Other Specifications .....	2-5
2-3. Accessories .....	2-8
2-4. Viewing the Functions .....	2-10
2-4-1. SMART Interaction .....	2-10
2-4-2. Smart Control .....	2-12
2-4-3. SMART HUB.....	2-16
2-4-4. Supported Formats.....	2-18
2-4-5. Satellite System Guide .....	2-20
<b>3. Disassembly and Reassembly .....</b>	<b>3-1</b>
3-1. Disassembly and Reassembly .....	3-1
<b>4. Troubleshooting .....</b>	<b>4-1</b>
4-1. Troubleshooting .....	4-1
4-1-1. Previous Check .....	4-1
4-1-2. Simple flow chart of malfunction .....	4-3
4-2. How to Check Fault Symptom .....	4-4
4-2-1. NO Power and No Video .....	4-4
4-2-2. Problems and Solutions.....	4-6
4-3. Factory Mode Adjustments .....	4-8
4-3-1. Detail Factory Option .....	4-8
4-3-2. Entering Factory Mode .....	4-9
4-3-3. Factory Data .....	4-10
4-4. White Balance .....	4-23
4-4-1. Calibration .....	4-23
4-4-2. Service Adjustment.....	4-23
4-4-3. Adjustment .....	4-25
4-5. RS-232C .....	4-26
4-6. AV Control Tab .....	4-27
4-7. Software Upgrade.....	4-33
4-7-1. How to Check the Software Version .....	4-33
4-7-2. How to Upgrade Software .....	4-34

**5. Wiring Diagram .....5-1**  
5-1. Wiring Diagram.....5-1  
5-2. Connector .....5-2  
5-3. Connector Functions .....5-6

**A. Exploded View & Part List [UE40F8000STXXH TS01] .....A-1**  
A-1. Exploded View ..... A-1  
A-2. Electrical Parts List..... A-3

**B. Exploded View & Part List [UE46F8000STXXH TH01] .....B-1**  
B-1. Exploded View ..... B-1  
B-2. Electrical Parts List..... B-3

**C. Exploded View & Part List [UE55F8000STXXH TH01] .....C-1**  
C-1. Exploded View ..... C-1  
C-2. Electrical Parts List ..... C-3



**This Service Manual is a property of Samsung Electronics Co.,Ltd.  
Any unauthorized use of Manual can be punished under applicable  
International and/or domestic law.**

**© 2013 Samsung Electronics Co.,Ltd.  
All rights reserved.  
Printed in Korea**